


## Smart Ceiling Fan WiFi Remote Control

## INSTALLATION & OPERATING INSTRUCTIONS

- 1. Install with WiFi APP
  - 1.1 To enjoy all the potential of your new device, you will need to download the BOND HOME app, available on the Google Play Store and Apple App Store
  - 1.2 Use the QR code presented in Figure 1 to download the app, or you can download the app using below link. <a href="http://bondhome.io/app">http://bondhome.io/app</a>










1.3 After you download the app, register new account and password.

NOTE: Please keep this account property, you will use this account when you connect with you smart speaker.

- 1.4 After you Log into the main page, you will see the "+ "on the right side of top space.
- 1.5 You will see ADD a new device screen, choose Smart by Bond. Then follow the config Wi-Fi process for to continue pairing
- 1.6 After the paring process with Wi-Fi receiver, you will be able control the fan speed and light functions on the app.







- 2. New router (or change setting) or Move ceiling fan controller
  - 2.1 Within 60 seconds of restoring power, press and hold "OFF" button at least 5 seconds. The light will flicker letting you know the controller is paired.
  - 2.2 Follow the 1.4 Add device to add the fan